

AIR-NET Laboratory Manual Version 5 08-04-2025

Study Title	AIR-NET- Testing anti-inflammatories for the treatment of bronchiectasis
IRAS	1010124
CI	Prof. James D Chalmers
Sponsor	University of Dundee & NHS Tayside
Associated Documents	<p>AIR-NET Sample Logs</p> <p>AIR-NET Assay Log</p> <p>AIR-NET Reagent Log</p> <p>AIR-NET Research Sample Receipt Log</p> <p>AIR-NET Video Protocols</p> <p>AIR-NET NEATstik Grading Sheet</p> <p>AIR-NET NEATstik Result Log</p>
Version history (and brief summary of changes)	<p>Version 1 14-11-2024</p> <p>Version 2 17-12-2024 updated research sample packs, SOP E update</p> <p>Version 3 21-01-2025 blood draw notes, overview, updated SOP J, K, L, M</p> <p>Version 4 31-01-2025 research samples v1 and safety/exacerbation visits, overview, updated SOPs B, D, H, J, K, L, M, Appendices 1, 2</p> <p>Version 5 8-4-2025 updated preparation list, updated SOP A, B, K, L, M</p>
Author	Dr Merete Long

Contents

1. Procedures.....	3
2. Equipment.....	3
2.1. Bloods.....	3
2.2. Sputum	4
2.3. Nasal brushing.....	4
3. Sample ID	5
4. Sample collection.....	6
5. Blood and Nasal Sample Processing Summary	8
5.1. Protocol summary	8
5.2. Preparation summary.....	11
5.3. Overview.....	13
6. Labelling Research Samples.....	15
7. Storing Research Samples.....	16
8. Detailed sample processing protocols.....	17
8.1. SOP A Sputum NEATstik (screening/v1 only)	17
8.2. SOP B Sputum aliquotting (visits 1, 2, 3, 4, 5, 6, and unscheduled).....	21
8.3. SOP C 4ml EDTA vacutainer tube storage (visit 3 and 4 only- do not store at visit 2 or 5)	23
8.4. SOP D Serum generation and aliquotting (visits 1, 2, 3, 4, 5, 6 and unscheduled)	24
8.5. SOP E Nasal epithelial cell brushing and storage (visits 2 and 5)	26
8.6. SOP F PAXgene tube storage (visits 2, 5, 6).....	27
8.7. SOP G Lithium heparin whole blood degranulation assay (visits 2, 5, and 6).....	28
8.8. SOP H Sodium heparin whole blood stabilisation and storage (visits 1, 2, 5, and 6, and unscheduled)	30
8.9. SOP I Neutrophil isolation with EasySep kit and neutrophil storage (visits 2 and 5)	32
8.10. SOP J <i>In vitro</i> neutrophil extracellular trap (NETs) assay with SYTOX green (visits 2 and 5)	36
8.11. SOP K <i>In vitro</i> neutrophil phagocytosis and reactive oxygen species assay (visits 2 and 5)	40
8.12. SOP L <i>In vitro</i> neutrophil stimulation in 12-well plates (visits 2 and 5).....	44
8.13. SOP M Flow cytometry analysis of ROS and phagocytosis assay samples (visits 2 and 5).....	47
9. Appendices.....	50
9.1. Appendix 1: <i>Pseudomonas aeruginosa</i> PAO1 confirmation of heat-killing for use in SOP K and de-classification from category 2 containment requirement.....	50
9.2. Appendix 2: Flow cytometry set-up and gating guide (before first participant baseline visit) ..	51

1. Procedures

- Ensure all equipment used is within expiry date
- Obtain blood samples as per local venepuncture Standard Operating Procedure, utilising 21G butterfly needle provided.
- Obtain spontaneous sputum samples as per local Standard Operating Procedure.
- Obtain nasal brushing samples as per instructional video and local Standard Operating Procedure.
- Dispose of all clinical equipment as per local policy.
- Deal with any needlestick injury or body fluid spillage as per local policies.
- Never put blood samples into the refrigerator or on ice.

Laboratories must adhere to Good Clinical Practise (GCP) guidelines, valid GCP certification should be obtained by any lab members processing research samples.

All equipment utilised should be regularly maintained and calibrated, including but not limited to fluorescence plate reader, flow cytometer, centrifuges and pipettes utilised, with in-date certification available.

2. Equipment

2.1. Bloods

- **Blood tubes as per visit**
- **Venepuncture equipment: 21G needle and vacutainer adapter provided to sites.** Tourniquet, cotton wool, alcohol wipes etc. to be utilised locally
- ***Collection set compatible with vacutainer tubes must be used for PAXgene tube (21G needle and adapter provided is sufficient)***
- **Research sample pack note**

Note for clinical research team: utilising a smaller needle for blood draw can result in haemolysis and in neutrophil activation due to increased shear force exerted on cells.

If it is attempted and subsequently deemed not possible to use a 21G needle, the smallest recommended alternative size is 23G. Please add a note onto the back of the sample pack note provided for the lab staff to record if needle size is changed.

For lab processing (summary- please refer to individual SOPs for comprehensive equipment list. Items in bold will be provided by Tayside central site, in addition to reagents listed in individual SOPs):

- **Sample labels**
- **Sample logs**
- **Black permanent marker pens**
- **Sample storage boxes**
- -20°C and -80°C freezers
- Refrigerator (4°C)
- **CoolCell freezing container (if required)**
- **CoolRack freezing block**
- **Cytodelics stabiliser solution**
- **5ml polystyrene tubes for flow cytometry (if required)**
- **0.9 ml fluid X tubes and caps**
- **1.8 ml Cryovials**
- **1.5 ml LoBind Protein Eppendorf tubes**

- **50 ml sterile blue-lidded falcon tubes**
- **15 ml sterile DNase/RNase free tubes**
- **96 well NUNC sterile tissue culture plates (transparent flat bottom)**
- **12 well sterile tissue culture plates (transparent flat bottom)**
- **Sterile disposable reagent troughs**
- p2.5, 10, 20, 200 and 1000 pipettes
- p10 and p100 (or p200) multichannel pipettes
- Filter tips for all pipettes (p2.5, 10, 20, 200, 1000)
- Centrifuge (large for 50ml tubes)
- Microcentrifuge (for 1.5ml tubes)
- Vortex
- Lab timer (10 min to 4h)
- 1.5ml, 15 ml, 50ml tube racks
- Light microscope or other similar cell counting equipment
- 37°C incubator with CO₂ (5%)
- Electronic pipette gun and 10ml and 25 ml sterile stripettes
- **StemCell Easy50 magnet (if required)**
- **StemCell neutrophil isolation kit and accompanying reagents**
- **Reagents for functional assays**
- Sterile dH₂O
- Ice and small ice container/box (*can be the same box as for sputum processing*)
- Fluorometer (fluorescent plate reader) for measurement of 96-well tissue culture plate assays
- Flow cytometer (capacity for APC and FITC fluorophore detection)

2.2. Sputum

- **Sputum sample pots**
- **NEATstik sputum elastase test and colour grade print-out**
- Screening only: camera or camera phone (if permitted locally) to photograph NEATstik result

For lab processing:

- **Sample storage boxes**
- **Sample Logs**
- **Pre-labelled 2 ml vials**
- **Positive displacement pipette and tips (if required)**
- -80°C freezer
- **DNA/RNA Shield reagent**
- p1000 pipette and tips
- ~10 cm sterile petri dish
- Ice and small ice container/box

2.3. Nasal brushing

- **3mm modified bronchoscopy brush**
- **5 ml cryotube containing 1 ml RNeasy lysis buffer**
- **Sample storage box**
- **Sample Logs**

note, nasal brushing and sample addition into RNeasy lysis buffer should be done during participant visit by clinical research team member

3. Sample ID

- Sample ID is made up of:
NET – site number – participant number – visit number
e.g. sample ID NET-01-003-02 would be site 01, participant 003, visit 02
n.b. Use “EX” for visit number for unscheduled visits due to exacerbation.
e.g. NET-01-003-EX

Version 5

4. Sample collection


Visit	NHS Labs	Research Blood Samples	Sputum Sample	Other research samples
1 screening	<p>Bloods:</p> <ul style="list-style-type: none"> FBC U&Es LFT <p>Urine:</p> <ul style="list-style-type: none"> Pregnancy test if required 	 <p>SST II Advanced 5 ml</p>  <p>Sodium Heparin (NH) 4 ml</p>	 <p>Min 0.4 g</p>	Nil
2 Day 0 (Baseline)	<p>Urine:</p> <ul style="list-style-type: none"> Pregnancy test if required 	 <p>SST II Advanced 5 ml</p>  <p>Sodium Heparin (NH) 4 ml</p>  <p>Lithium Heparin (LH) 4 ml</p>  <p>EDTA (K2E) 24 ml (2x10ml, 1x4ml)</p>  <p>PAXgene RNA tube 2.5 ml</p>	 <p>Min 0.4 g</p>	 <p>Nasal brushing (3mm brush and 5ml cryotube with 1ml RNAlater solution)</p>
3 Day 7	<p>Urine:</p> <ul style="list-style-type: none"> Pregnancy test if required 	 <p>SST II Advanced 5 ml</p>  <p>EDTA (K2E) 4 ml</p>	 <p>Min 0.4 g</p>	Nil
4 Day 14	<p>Urine:</p> <ul style="list-style-type: none"> Pregnancy test if required 	 <p>SST II Advanced 5 ml</p>  <p>EDTA (K2E) 4 ml</p>	 <p>Min 0.4 g</p>	Nil


<p>5 Day 28</p>	<p>Bloods:</p> <ul style="list-style-type: none"> FBC U&Es LFT <p>Urine:</p> <ul style="list-style-type: none"> Pregnancy test if required 	     <p>SST II Advanced 5 ml</p> <p>Sodium Heparin (NH) 4 ml</p> <p>Lithium Heparin (LH) 4 ml</p> <p>EDTA (K2E) 24 ml (2x10ml, 1x4ml)</p> <p>PAXgene RNA tube 2.5 ml</p>	 <p>Min 0.4 g</p>	 <p>Nasal brushing (3mm brush and 5ml cryotube with 1ml RNAlater solution)</p>
<p>6 Day 56</p>	<p>Bloods:</p> <ul style="list-style-type: none"> FBC U&Es LFT 	    <p>SST II Advanced 5 ml</p> <p>Sodium Heparin (NH) 4 ml</p> <p>Lithium Heparin (LH) 4 ml</p> <p>PAXgene RNA tube 2.5 ml</p>	 <p>Min 0.4 g</p>	<p>Nil</p>
<p>Unscheduled NHS bloods as clinically indicated</p> <ul style="list-style-type: none"> FBC U&Es LFT 		  <p>SST II Advanced 5 ml</p> <p>Sodium Heparin (NH) 4 ml</p>	 <p>Min 0.4 g</p>	<p>Nil</p>


5. Blood and Nasal Sample Processing Summary

5.1. Protocol summary

IMPORTANT NOTE: see section 8 for detailed protocols. Section 5 is for quick-reference purposes only, detailed step-by-step procedures from section 8 should always be followed.

TUBES	INVERT TUBE (at visit blood draw only)	ALLOW TO STAND	CENTRIFUGE	TRANSFER	LABEL	FREEZE
 <p>PAXgene RNA tube</p>	 <p>8-10 times <i>(at visit blood draw only)</i></p>	 <p>Stand upright minimum 2 hours from blood draw</p>	n/a	n/a	 <p>Add label directly to vacutainer</p>	 <p>Store upright Transfer to -80°C freezer within 2-24 hours from collection (storage up to 72h permitted for weekends)</p>
 <p>SSTII Advance</p>	 <p>5 times <i>(at visit blood draw only)</i></p>	 <p>Stand upright 30 mins, process within a maximum of 2h from draw.</p>	 <p>1000 xg for 15 mins</p>	 <p>Transfer 0.4 ml serum into each of 3x 0.9 ml FluidX tubes, add remaining excess to a 4th tube. Cap tubes.</p>	 <p>Dot the cap of the 4th/excess tube with a permanent marker. Firmly add labels to each of the 4 tubes.</p>	 <p>Store upright Transfer to -80°C freezer</p>
 <p>4 ml EDTA (K2E) Visits 3 and 4 only *Do not store 10ml EDTA tubes (use for neutrophil isolation) and do not store 4 ml tubes on visits 2 and 5.</p>	 <p>8-10 times <i>(at visit blood draw only)</i></p>	n/a	n/a	n/a	 <p>Add label directly to vacutainer</p>	 <p>Store upright Transfer to -80°C freezer within 1 hour from collection</p>

TUBE	INVERT TUBE	ALLOW TO STAND	TRANSFER	INVERT	ALLOW TO STAND	LABEL	FREEZE 1	FREEZE 2
 Sodium Heparin (NH)	 5-10 times <i>(at visit blood draw only)</i>	 Stand upright 15 mins (if already 15 min post-draw, continue immediately)	 Within 1 hour from draw, transfer 0.5 ml blood to each of 4x 1.8ml cryovials containing pre-aliquotted stabiliser (0.5ml)	 Invert filled cryovials 15 times. <i>1 full inversion = 180° degree turn and back to original position again</i>	 Stand upright 10 mins at room temp	Label the 4 cryovials	Store upright in round CoolCell freezer container, with filler vials in empty spaces. Add to -80°C freezer. 	Transfer to storage box in -80°C freezer 4-72 hours after storage in CoolCell 

TUBE	INVERT TUBE	TRANSFER	INVERT TUBE	INCUBATE	CENTRIFUGE	TRANSFER	LABEL	FREEZE
 Lithium Heparin (LH)	 5-10 times <i>(at visit blood draw only)</i>	Within 1 hour from blood draw, add 750µl blood to each of 4 Eppendorf tubes containing pre-warmed zymosan (x2) or HBSS (x2)	Cap tubes very tightly  5 times	 Incubate samples upright in a tube rack at <u>37°C</u> for <u>30 min exactly</u>	 Invert tubes 2 times then immediately centrifuge 600 xg for 10 mins	<u>Immediately</u> after centrifuge completion, aliquot 200µl plasma into one 0.9ml fluidX tube per original Eppendorf tube (4 total). <u>Do not transfer any buffy coat/RBCs.</u>	Label 0.9ml FluidX tubes: 2x Zymosan 2x HBSS	 Store upright in FluidX box Transfer to -80°C freezer

*note for clinical research team: LH tube filling upon blood draw can be slow, allow time for the vacutainer to fill sufficiently

SAMPLE	LABEL	COLLECT <i>*Note, this step should be done by the clinical research team member performing the participant visit*</i>	LABEL AND FREEZE
 Nasal Brushing (3mm)	Pre-label a 5 ml cryotube containing 1 ml RNALater buffer (as supplied).	Immediately after obtaining nasal brushing sample, vigorously agitate brush in RNALater buffer for 30 seconds to release cells from sample brush. Lower the plastic sheath of the brush to remove any remaining cells Dispose of the brush in a sharps bin. See video protocol for brushing procedure for clinical research team	In the lab, add sample directly into storage box in -80°C freezer. Complete log sheet. 

TUBE	INVERT TUBE	TRANSFER, AND BEGIN ISOLATION	MAGNET 1	TRANSFER	MAGNET 2	TRANSFER, MAGNET 3
Visit 2 and 5 only  2x10 ml EDTA (K2E) plus 1x4ml EDTA (K2E)	 8-10 times <i>(at visit blood draw only)</i>	Within 1 hour from blood draw, gently pour blood (45° angle) into blue-lidded 50ml Falcon tube. Add 50µl Ab cocktail and 50µl pre-vortexed bead solution, per ml whole blood. Gently invert 4X to mix. Incubate 5 min, room temp.	Top up to final volume 50ml with DPBS/EDTA. Gently invert 3X to mix. Incubate on StemCell Easy50 magnet 10 min, without lid. 	Transfer the neutrophil-rich plasma layer to a new 50ml falcon. Add beads (same vol as first addition). Invert 3X to mix. Incubate in a rack for 5 mins. 	Remove tube lid. Add tube to magnet. Incubate in magnet for 5 mins. 	Again transfer the purified neutrophil-rich plasma to a new 50ml falcon. Remove lid, add to magnet. Incubate a final time for 10 min. 
TRANSFER, COUNT, CENTRIFUGE	WASH CELLS	RESUSPEND NEUTROPHILS	PART OF CELL SUSPENSION: TRANSFER, CENTRIFUGE	PART OF CELL SUSPENSION: STORE	FUNCTIONAL ASSAYS	
Transfer neutrophil-rich plasma to a new 50 ml tube. Note the final volume. Add 10 µl cell suspension to haemocytometer. Centrifuge cells. Perform count.  300 xg for 6 mins low brake RT	Discard supernatant. Gently resuspend cell pellet in 10ml DPBS (no EDTA). Centrifuge cells to wash and pellet.  300 xg for 6 mins low brake RT	Discard supernatant. Resuspend pellet at 5x10 ⁶ cells/ml in DPBS according to cell count calculation. <i>Priority for use:</i> -1x Pellet storage -1x RNALater storage -Functional work -2x further pellet storage	Add 1ml cell suspension to each of 3x pre-labelled 1.5ml LoBind Eppendorf tubes (if count allows). Pellet cells.  300 xg for 5 mins RT	Discard supernatant from 1.5ml Eppendorfs. Store 3x tubes in pre-cooled block at -80°C. 3 rd tube: Resuspend cells in 100µl DPBS, add 500µl RNALater. Pipette 10X. Store in -80°C freezer. Log all samples.	Use live neutrophil suspension at 5x10 ⁶ cells/ml for functional assays: <ul style="list-style-type: none"> - NETs - Phagocytosis - ROS - In-plate cell stimulation 	

5.2. Preparation summary

Before sample receipt, run through preparation checklist (begin minimum ~1h before samples arrive, points with an asterisk (*) could also be prepared the day(s) before, if wanted):

- Ensure centrifuges are at room temperature (i.e. no pre-cooling)
- 2 ml screw-capped tubes for sputum (Visits 2, 3, 4, 5, 6):
 - *Add 5x tubes to a rack ready for use. Retrieve sputum labels, but wait for sample to arrive to complete since not all aliquots may be possible for small samples
 - Prepare a small cooler container/box with ice
- Nasal brushing (Visits 2 and 5):
 - Ensure brush and 1x 5 ml cryotube containing RNAlater buffer are available to the clinical team, clinical team can pre-label tube (this is provided to clinical sites within visit sample pack)
- 4ml EDTA to store (at **visit 3 and 4 ONLY**):
 - *Complete 1x label ready for vacutainer addition with participant details and date
- SSTII Advance (Visits 2, 3, 4, 5, 6):
 - *Label 4x 0.9ml FluidX tubes with participant details and date and keep sterile in hood. Ensure septum caps are available.
- Sodium heparin (Visits 2, 5, 6):
 - Remove 4x 1.8ml cryovials containing 0.5ml aliquots of stabilisation buffer from the fridge (or generate these aliquots from stock bottle if required). Allow aliquots to warm to room temperature at least 15 min (maximum 2h) before use.
 - *Label the 4 cryovials with stabilised blood labels, sample ID and date using appropriate AIR-NET study labels.
 - *Check the round CoolCell freezer container is at room temperature (after any previous samples are removed and stored). If CoolCell is still in the freezer due to previous sample processing, appropriately store any previous frozen samples at -80°C, then take out freezing container and keep at room temperature at least 1 hour before use.
- Lithium heparin (Visits 2, 5, 6):
 - Remove 2x zymosan and 2x HBSS aliquots (1.5ml Eppendorf tubes containing 75µl reagent) from -20°C freezer. Allow to warm to room temperature minimum 10 mins (max. 30 mins) before use.
 - *Label 4x 0.9ml FluidX tubes (2 per condition) with the appropriate experimental condition labels (2xzymosan, 2xHBSS) and add sample ID and date.
- 2x10ml EDTA tubes, plus 1x4ml EDTA tube (**Visit 2 and 5 only**):
 - *Ensure sufficient volume of necessary reagents is available, generate more if needed:
 - DBPS (supplied ready to use)
 - DPBS/1mM EDTA (supplies ready to use)
 - RPMI/10mM HEPES (prepared by site)
 - RPMI/10mMHEPES/10%FBS (prepared by site)
 - Fill cooler box (polystyrene box is acceptable) with ice.
 - *Check the grey metal cold block is in the -80°C freezer and is empty of any previous samples (store these as appropriate if present).


- Make up complete RIPA/SDS/PMSF/PI/PhosSTOP (add PMSF, PI, PhosSTOP on day of use only, do not re-use) and store on ice until use. **PMSF stock is generated in alcohol, use immediately from freezer, do not keep stock on ice before use as it will evaporate.**
- Generate 96-well plate with media and stimulants for NETs assay and store in fridge until 30 mins before use. Do not generate DNA standard curve yet.
- Add media to 12-well plate appropriate wells and label (don't add stimulants yet). Store in the fridge until 30 min before use, then take out to warm to room temp.
- Remove the 1.5ml Eppendorfs for the ROS experiment from the freezer and thaw for 5-10 mins
 - 2x HBSS tubes for subsequent LPS+TNF addition (“L/T” to warm to room temp)
 - 4x HBSS control tubes (“H/O” to warm to room temp)


Dilute the 1000X TNF stock by addition of 180 ul sterile PBS directly to the 20 ul aliquot tube. Vortex for 3 seconds to mix. Keep on ice at all times until use, and return to ice directly after.

After 5-10 mins, add to the 2x “L/T” tubes 2.3 µl of 100X LPS stock and 2.3 µl of TNF-alpha stock to each tube. Add all 6 tubes to the fridge until later use.
- *Label 1.5ml LoBind Protein Eppendorf tubes:
 - 3x Neut pellet (2 of these are “spare” if enough cells once isolated)
 - 1x Neut RNAlater
 - 2x Neut RIPA lysate PBS
 - 2x Neut RIPA lysate TNF
 - 2x Neut RIPA lysate LPS
- *Label 0.9ml FluidX tubes:
 - 2x Neutrophil supernatant PBS
 - 2x Neutrophil supernatant TNF
 - 2x Neutrophil supernatant LPS
 - 2x Neutrophil supernatant PBS (no cells)

5.3. Overview

Lab Sample Processing





Recommended timings and order of processing/assays for day 0 and day 29 (visits 2 and 5) sample sets

*Sputum- if sputum sample is not received at the same time as blood samples and is brought to the lab later in the day, keep sputum sample on ice and process as soon as time is available (e.g. during functional assay incubation periods such as 12-well plate 30 min incubation)

Never put blood tubes in the fridge/on ice for any amount of time

6. Labelling Research Samples

- Sample pack note should be included in the visit pack with sample tubes and should be completed at the visit by clinical team member. Vacutainers need only to be labelled with the sample ID, date and time using the manufacturers label by clinical team.

<p>AIR-NET research samples</p> <p>Participant ID: NET- ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p> <p>Blood and nasal sampling time: ____ : ____</p> <p>Sputum production time: ____ : ____</p> <p>Staff initials: ____</p>
--

- All research samples (i.e. all samples not for NHS analyses) including vacutainers for storage should be labelled in the lab with the labels provided by the lab team member, with the exception of the Nasal Brushing (see SOP E).

<p>AIR-NET Whole Blood (4ml EDTA)</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Serum</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Sodium heparin, stabilised 0.5 ml</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Degran. Plasma Zymosan-treated</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>
<p>AIR-NET PAXgene</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Neut. pellet</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Neut. RNAlater</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Degran. Plasma HBSS-treated</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>
<p>AIR-NET Neut. RIPA lysate PBS</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Neut. RIPA lysate LPS</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Neut. RIPA lysate TNF</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Nasal brushing RNAlater</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>
<p>AIR-NET Neut supernatant PBS</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Neut supernatant LPS</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Neut supernatant TNF</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Neut supernatant PBS (no cells)</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>
<p>AIR-NET Excess Sputum</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Sputum 100 uL</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Sputum 200 uL</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>	<p>AIR-NET Sputum DNA/RNA shield</p> <p>NET - ____ - ____ - ____</p> <p>Date: ____ - ____ - ____</p>

- The appropriate sample label should be used for whole blood, serum, sodium heparin stabilised blood, PAXgene, lithium heparin degranulation assay plasma, neutrophil pellets, neutrophils in RNAlater buffer, nasal brushing or sputum samples.
- Ensure labels are attached **prior** to freezing. Ensure that the label is **firmly rubbed** on to the tube to prevent it coming off.
- Complete each label with full sample ID and date as below.
- Date to be filled in day-month-year i.e. 30-05-25
- All samples should be logged on the appropriate AIR-NET Sample Log in the lab.

7. Storing Research Samples

- The samples should be stored in the storage boxes provided.
- Study samples should be stored in separate boxes according to sample type.
- The storage boxes should be labelled with study title, site number, sample type, and box number.
- Sample receipt log, storage log, and assay log should be completed.
- No identifiable patient details (e.g. name, CHI number, date of birth) should be associated with processed research samples when shipping back to Tayside.

8. Detailed sample processing protocols

8.1. SOP A Sputum NEATstik (screening/v1 only)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	Microbiological Safety Cabinet MSCII
Lab coat	Sterile petri dishes
Clinical waste bags & autoclave tape (or as per local procedures)	Timer
1x NEATstik pack (ProAxis) (stored at room temp)	Vortex
Camera/camera phone	P1000 and p200 pipette and filter-tips
2ml screw-capped tubes (CP5935)	Printed disposable grading sheet (in lab folder)
Ice and small ice box	P100 positive displacement pipette and tips

Notes

No patient detail, (name, CHI number) should be associated with processed samples in the lab.

NEATstik pack should contain:

1x lateral flow test

1x 20ml sample dilution buffer

1x sputum dilution pot (*not required for this protocol; can be disposed of once pack is opened*)

1x dual-bulb pipette (*not required for this protocol; can be disposed of once pack is opened*)

1x graduated pipette (*not required for this protocol; can be disposed of once pack is opened*)

1x instruction leaflet

Procedure:

1. Upon receipt of sputum sample to the lab, keep on ice until use.
2. Add sputum sample to a sterile petri dish to allow selection of sputum and elimination of any contaminating saliva present in the sample. Sputum can be distinguished from saliva typically by its colouration and higher viscosity.
3. Using a p100 MicroMan positive displacement pipette set to 100 μ L, select out the sputum, combining into a separate area of the petri dish if needed (e.g. if sample has high saliva content and small separated bits of sputum). **Visually check the sputum taken up into the pipette tip; if there are bubbles or a notable proportion of contaminating saliva, pipette the sample back out**

into the dish and repeat the procedure. Presence of air in the tip will result in inaccurate sputum volume being utilised.


4. Transfer exactly 100 µl of sputum to the sterile 2ml screw-capped tube, after checking no air bubbles are present in the tip, as above.
4. Add NEATstik sample dilution buffer from the kit, to produce a 10x dilution (i.e. to 100 µl sputum, add 900 µl of the buffer)
5. Cap the sample tightly and vortex at high speed (approx. 2,000 rpm) for 15 seconds. Pipette the sample up and down with a p1000 pipette to break up the sputum sample 10 times, or until no large lumps are observed. Allow sputum to settle for 1 min by placing in a rack (room temperature).

Perform the test:


6. Remove the NEATstik lateral flow test from the foil packaging and place on a level surface with viewing window facing upwards.
7. Use a p200 pipette to add 125 µl of sputum/buffer mixture to the sample port, ensuring no lumps of sputum are transferred (if lumps are very hard to avoid, carefully remove lumps from the tube by pipetting lumps out into a new petri dish to remove them, then discard to waste after loading test).
9. Once sample is added, incubate at room temp in a hood for 10 mins (set a timer).
10. After 10 min, read and record the result (see result guide below for how to read and QC assay). Add the sample ID and the date to the test with permanent marker, circle the final score decided upon on the printed grading sheet, then take a photograph of the lateral flow test result placed on top of a disposable printed grading sheet. Dispose of the test and all associated equipment into the appropriate waste stream.

Reading the result and Quality Control


If the test has been performed successfully, the CONTROL (C) line will be visible as a red line (colour intensity may vary). If the CONTROL (C) line is not visible, the results are invalid and the test should be repeated with a new sample and a fresh test kit.




If the TEST (T) line is visible, this confirms the presence of active NE greater than the pre-set threshold, in the sputum sample.




If the TEST (T) line is not visible, any active NE present in the sputum sample does not exceed the pre-set threshold.



test result scoring guide (utilise print out provided, if needed print further copies from "NEATstik grading sheet" file. Always print in colour and ensure no discolouration is transferred from the printer)



Example photograph and labelling (positive test is shown)



8.2. SOP B Sputum aliquotting (visits 1, 2, 3, 4, 5, 6, and unscheduled)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	Microbiological Safety Cabinet MSCII
Lab coat	Sterile petri dishes (ideally 10 cm)
Clinical waste bags & autoclave tape (or as per local procedures)	P100 positive displacement pipette and corresponding piston tips
2 ml sterile screw-capped tubes	Ice and small ice box/container
DNA/RNA shield (stored at room temp)	Sputum sample labels (use appropriate 100 or 200 µl, DNA/RNA shield, or Excess)

Note:

If multiple samples (e.g. early morning sputum and sputum sample produced at the visit) are provided, apply the aliquotting procedure to each sample individually.

Mark the generated aliquot tube lids pertaining to each original sputum sample sequentially with “1”, “2”, to indicate in chronological order which sample the aliquot originated from.

For example, all aliquots from an early morning sample would be marked on their lid with “1”, all from a subsequently produced visit sample would be marked with “2”. If a sample is only provided at the visit, all aliquots would be marked with a “1” since chronologically this is the first sample produced/provided by the participant on that day.

Procedure:

1. Upon receipt of sputum sample to the lab, remove sputum pot from the delivery packaging, wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures and dispose of the tissue. Ensure pot has dried off before opening.
2. In the event of contamination of packaging (i.e. sample has leaked into packaging), attempt to rescue as much uncompromised sample as possible, decontaminate the delivery packaging as per local SOPs, and make a note of this in the log.
3. Keep sputum sample on ice until use.

On visits 2 and 5, if sputum sample is not received at the same time as blood samples and is brought to the lab later in the day, keep sputum sample on ice and process as soon as time is available (e.g. during functional assay incubation periods such as 12-well plate 30 min incubation)

4. Add sputum sample to a sterile petri dish to allow selection of sputum and elimination of any contaminating saliva present in the sample (note: saliva contamination will impact assay results and study endpoint measurements, take care to ensure saliva is not transferred for storage).

5. Using a p100 MicroMan positive displacement pipette set to 100 μ L, select out the sputum, combining into a separate area of the petri dish if needed (e.g. if sample has high saliva content and sputum sections are small).
6. Transfer 100 μ l of selected sputum to sterile 2 ml screw-capped tube, with the following order of priority:
 1. 2x 100 μ l aliquots (i.e. two tubes, final sputum volume of 100 μ l per tube)
 2. 1x 200 μ l aliquot (use the p100 to pipette two lots of 100 μ l sample into these tubes for a total of 200 μ l sputum per tube)
 3. 1x 100 μ l aliquot plus 900 μ l DNA/RNA shield buffer (method: add 900 μ l DNA/RNA shield buffer to aliquoted sputum sample, cap tightly and vortex for 15 seconds at high-speed (approx. 2,000-3,000 rpm) to mix. Pipette up and down 10X with a p1000 pipette to disperse lumps.
 4. 1x further 200 μ l aliquot (use the p100 to pipette two lots of 100 μ l sample into these tubes for a total of 200 μ l sputum per tube)
 5. Add any remaining excess sputum into as many 2 ml tubes as required to store all sputum, adding a maximum final volume of 1 ml per tube to avoid over-filling.

If sample volume is too low for any of the study visits and aliquots for 1. or 2 in the list above. above cannot be achieved, store any sputum available, by reducing the pipette volume setting and record the accurate final volume in the log sheet notes section.

7. Store all samples in AIR-NET sputum box in the -80°C freezer immediately after aliquotting is completed. Record sample details in the sputum log sheet. Add any notes (including approximate excess sputum volumes or any volumes below 100 or 200 μ L if sample volume was low).

8.3. SOP C 4ml EDTA vacutainer tube storage (visit 3 and 4 only- do not store at visit 2 or 5)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	Microbiological Safety Cabinet MSCII (or as appropriate for locally approved procedures)
Dedicated lab coat	EDTA 4ml vacutainer tubes containing blood
Clinical waste bags & autoclave tape (or as per local procedures)	Sample label (1 per participant)
Cardboard tube storage box	

Procedure (processing should be completed within maximum 1hr of collection):

1. Remove the 4mL EDTA vacutainer from the delivery packaging, wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures.
2. In the event of contamination of packaging (i.e. sample has leaked into packaging), attempt to rescue as much uncompromised sample as possible, decontaminate the delivery packaging as per local SOPs, and make a note of this in the log.
3. Add the sample label to the blood tube and fill out sample log. Then place immediately in cardboard storage box provided (upright) in -80°C freezer.
4. Record details in the AIR-NET log sheet, including notes such as low blood volume in tube if noticed.

8.4. SOP D Serum generation and aliquotting (visits 1, 2, 3, 4, 5, 6 and unscheduled)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	P1000 Pipette and Filter tips
Dedicated lab coat	1x SSTII Advance 5ml vacutainer tube containing clotted blood
Centrifuge (room temp)	Serum sample labels (4 per sample/visit)
Microbiological Safety Cabinet MSCII	FluidX 0.9mL tubes (4 per sample) and yellow septum caps (4 per sample)
Clinical waste bags & autoclave tape (or as per local procedures)	FluidX 96-well box for serum

Procedure (processing should be completed within maximum 2hrs of collection):

1. Remove the 5mL SSTII yellow-topped vacutainer from the delivery packaging, wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures.
2. In the event of contamination of packaging (i.e. sample has leaked into packaging), attempt to rescue as much uncompromised sample as possible, decontaminate the delivery packaging as per local SOPs, and make a note of this in the log.
3. Allow the tube to stand upright for 1 h at room temperature (i.e. 1h from time of blood draw). If 1h has already passed from time of venepuncture when the sample is received to the lab, proceed directly to further processing.
4. Turn on centrifuge. Follow safe use of the rotors and lids for this unit paying particular attention to correct balancing of samples in the appropriate rotor for each sample process. Ensure centrifuge is at room temperature.
5. Place the vacutainer tube in the rotor bucket with the appropriate blood tube adaptor and vacutainer counterbalance. Centrifuge the tubes at 1000 xg for 15 mins.
6. Label 4x FluidX tubes (white freezer-safe labels) with sample ID, visit number, and date.
7. Remove the vacutainer from the centrifuge carefully and transfer back into the MHCII hood (or as per local procedures).
8. Pipette 400 μ l aliquots of serum using a P1000 and sterile filter tips into four 0.9mL FluidX tubes. Aliquot any excess serum into the final (i.e. 4th) tube. *If excess is more than 800 μ l, also add in 400 μ l increments to the 3rd tube, 2nd tube, 1st tube, in that order, if required, to avoid over-filling.*

In the case than <400 μ l is available, aliquot this anyway and make a note of the approximate volume in the log sheet.

9. Cap the samples with yellow septum caps. Add one dot with permanent marker to the cap of the “excess” tubes to indicate extra volume. Also add a dot to the cap if a tube has <400 µl in the case of low volume.
10. Record details in the sample log sheet, including any important notes (for example if haemolysis is noticed or if timing was not possible to keep to).
11. Place all aliquoted sera in clearly labelled FluidX 96 well boxes and store at -80°C.

Version 5

8.5. SOP E Nasal epithelial cell brushing and storage (visits 2 and 5)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	5ml cryotube tube containing 1ml of 1X RNAlater buffer (stored at room temp; provided in sample pack)
Dedicated lab coat	Nasal brush (modified 3mm bronchoscopy brush; provided in sample pack)
Cardboard sample storage box for brushings	Brushing sample label (1 per sample; provided in sample pack)
	Sample bag and absorbent material

Notes:

For nasal brushing procedure to obtain this sample, please refer to instructional video.

Procedure:

1. Label the tube before performing the brushing procedure, including participant ID and date.
2. At the study visit, immediately after obtaining brushing, **the clinical team member** should vigorously agitate the brush in RNAlater solution in a 1.5 ml LoBind Eppendorf tube for 30 seconds to ensure all cells have been detached from the brush into the solution. The plastic sheath of the brush can be lowered over the brush to remove remaining cells.
3. Cap the tube very tightly and securely.
4. Add sample to the sample bag together with absorbent material.
5. *Upon receipt in the lab, wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures).*
6. Transfer the 1.5ml tube to the permanent storage box in a -80°C freezer.
7. Record details in the sample log sheet, add any important notes, including any presence of red blood cells.

8.6. SOP F PAXgene tube storage (visits 2, 5, 6)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	Microbiological Safety Cabinet MSCII
Dedicated lab coat	2.5mL PAXgene vacutainer tubes containing blood
Clinical waste bags & autoclave tape (or as per local procedures)	1x Sample label
Cardboard boxes for tube storage	-80°C freezer

Procedure (process ideally within 4h from blood draw):

1. Remove the PAXgene RNA vacutainer from the delivery packaging, wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures.
2. In the event of contamination of packaging (i.e. sample has leaked into packaging), attempt to rescue as much uncompromised sample as possible, decontaminate the delivery packaging as per local SOPs, and make a note of this in the log.
3. Add a sample label with site, participant ID, visit number, and date. Store the PAXgene tube upright for at least 2 hours and no more than 6h (from time of venepuncture) at room temperature before transferring to -80°C freezer storage.
4. Record details in the log sheet, including any notes (e.g. low blood sample volume, if this occurs).

8.7. SOP G Lithium heparin whole blood degranulation assay (visits 2, 5, and 6)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	FluidX 0.9mL (4 per participant)
Designated Lab coat /safety glasses	FluidX blue septum caps (4 per participant)
Centrifuge	Tube labels (4 per participant)
Microbiological Safety Cabinet MSCII	Incubator (37°C, 5% CO ₂)
Clinical waste bags & autoclave tape (or as per local procedures)	Zymosan (2x 75 µl aliquots in 1.5 ml tubes; 10 mg/ml stock concentration in HBSS) (stored at -20°C)
P1000 and P200 pipettes and filter tips	HBSS (2x 75 µl aliquots in 1.5ml tubes) (stored at -20°C)
Green topped 4ml lithium heparin (LH) vacutainer with whole blood	

Notes

Process within maximum 2h of venepuncture, ideally within 1h.

Assay timings below must be exact, do not leave samples in the incubator or centrifuge once completed as neutrophils will continue to degranulate and significantly impact endpoint measurements.

Procedure

1. Remove the 4ml lithium heparin (LH) vacutainer from the delivery packaging, wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures. Ensure the correct LH tube has been selected (distinct from “NH” tube)
2. In the event of contamination of packaging (i.e. sample has leaked into packaging), attempt to rescue as much uncompromised sample as possible, decontaminate the delivery packaging as per local SOPs, and make a note of this in the log.
3. Remove 2x stored Zymosan aliquots and 2x HBSS aliquots containing 75 µl (per 1.5ml tube) of appropriate reagent from -20°C freezer. Ensure Z or H is clearly labelled on tube lid and allow to thaw and bring to room temp for 10 min before use (maximum 30 min). Label the Eppendorf tubes with the participant ID.
4. Label 2 x FluidX 0.9ml tubes for plasma from Zymosan-treated blood and 2 x FluidX 0.9ml tubes for the control plasma aliquots.
5. Add 750 µl of blood into the 4 labelled Eppendorf tubes. Use a new p1000 tip for each tube.
6. Invert the tubes 5 times to mix, ensuring the white zymosan pellet is no longer visible, and incubate the tubes for 30 minutes at 37°C in an incubator (5% CO₂). Use the lab timer for precision.
7. At exactly 30 mins, invert the tubes twice to resuspend the blood cells, then immediately centrifuge at 600xg for 10 mins at room temperature.

8. As soon as the centrifuge cycle has finished (note: timing must be exact), immediately aliquot the separated plasma supernatants (200 µl per tube) from the Eppendorf tubes into a 0.9mL FluidX tubes for each original sample tube (4 FluidX tubes in total).
DO NOT DISTURB THE WHITE BUFFY COAT LAYER between the plasma and the red blood cells-
this will result in cell contamination and affect plasma protein assays.
9. Store plasma aliquots at -80°C immediately. Update freezer sample log.
10. Remaining red cell pellets in Eppendorf tubes can be discarded to waste bag or liquid waste, according to local procedures.

Version 5

8.8. SOP H Sodium heparin whole blood stabilisation and storage (visits 1, 2, 5, and 6, and unscheduled)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	Microbiological Safety Cabinet MSCII
Dedicated lab coat	Green topped sodium heparin (NH) 4ml vacutainer tubes containing whole blood
Clinical waste bags & autoclave tape (or as per local procedures)	Sample labels (4 per participant)
Cardboard tube storage box	Stabilisation buffer (Cytodelics; from whole blood processing kit/Gen 2); 500 µl/tube (Stored at 4°C)
4 x 1.8 ml cryovials	8x “filler vials” for unoccupied CoolCell spaces (i.e. 8x 1.8 ml cryovials, filled with 1 ml PBS per vial)

Notes:

On /before the first use, generate 8x “filler vials” which should be placed into any unoccupied spaces in the CoolCell freezing container when samples are being frozen. For this, add 1ml of sterile PBS into 8x 1.8 ml cryovials. Re-use filler tubes as many times as needed, but check volume remains at 1ml over multiple uses and top-up tubes or remake as required. Label these clearly with black permanent marker as “FILLER” and add a dot to the cap to distinguish easily from stored blood samples.

Cryovials with 0.5ml stabilisation buffer to be stored in fridge, prepare aliquots in advance as required. **Before use, buffer must come up to room temperature.**

Round CoolCell freezer containers to be stored at room temperature after any samples have been appropriately removed and stored. **If CoolCell is still in the freezer due to previous sample processing, appropriately store any previous frozen samples at -80°C, then take out freezing container and keep at room temperature at least 1 hour before use.**

Procedure (within 1h from blood draw):

1. Remove stabilisation buffer aliquots from fridge (500 µl per tube) and bring to room temp (~10-15 min before use, maximum 30 mins before).
2. Remove the 4ml sodium heparin (NH) vacutainer from the delivery packaging wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures. Ensure the correct tube (NH, *not* LH) has been selected from the sample pack.
2. In the event of contamination of packaging (i.e. sample has leaked into packaging), attempt to rescue as much uncompromised sample as possible, decontaminate the delivery packaging as per local SOPs, and make a note of this in the log.

3. Label 4 x 1.8 ml cryovials containing stabilisation buffer with the ID, visit, and date using white label provided.
4. Just prior to aliquotting, gently invert the NH vacutainer twice to mix to ensure plasma and blood cells are not separated.
4. Add 500 µl NH whole blood to 500 µl room-temperature stabilisation buffer in each of the four cryovials.
5. Cap the cryovials and gently invert 15 times to mix - **DO NOT VORTEX**
6. Incubate in the hood at room temperature (ideally ~20°C) upright for 10 mins (use lab timer).
8. Place in CoolCell cryobox (upright) in -80°C freezer. Add details to log sheet.
9. After a minimum of 4h (maximum is indefinite), transfer the frozen cryovials to a permanent storage box. Ensure this is done rapidly so that samples do not thaw.
10. Record sample location in log sheet.

8.9. SOP I Neutrophil isolation with EasySep kit and neutrophil storage (visits 2 and 5)

Equipment/ reagents required:

Nitrile gloves	StemCell EasySep Neutrophil Isolation Kit (cat no 196666) (stored at 4°C)
Dedicated lab coat	Blue lid 50ml Falcon Tube (4 per participant)
Centrifuges (for 50ml tubes and 1.5ml Eppendorf tubes) at room temp	DPBS + 1mM EDTA (no Ca ²⁺ or Mg ²⁺) <i>Provided pre-made to site, stored at room temp</i>
Microbiological Safety Cabinet MSCII	1X DPBS (no Ca ²⁺ or Mg ²⁺) <i>Provided pre-made to site, stored at room temp</i>
Clinical waste bags & autoclave tape (or as per local procedures)	Electronic pipette (for 10-25 ml stripettes)
Haemocytometer (glass or plastic)	Microscope (or equivalent cell counting equipment)
2x Purple-topped 10ml EDTA blood vacutainers, 1x 4ml EDTA vacutainer	Easy 50 silver magnet (provided if required by site)
Disposable sterile 25ml and 10 ml stripettes	4x Eppendorf 1.5ml LoBind tubes, 4x white labels (3x neutrophil pellets, 1x RNALater)
RNALater (provided to site as 5ml tubes) (stored at room temp)	P10, 200, 1000 pipettes and tips
Pre-cooled Corning CoolRack (keep at -80°C)	

Notes:

Please familiarise yourself with the instruction materials provided by StemCell - Product Information Sheet and Safety Data Sheet.

Minimum expected yield from 1ml EDTA blood is typically 1 million isolated neutrophils.

Neutrophils are very sensitive and are easily activated. Do not vortex any samples containing neutrophils, treat the cells very gently, and avoid bubbling through any of the cell solutions at any step.

Procedure (process within maximum 2h from blood draw, ideally no more than 1h):

1. Remove the 2x 10ml and 1x 4ml purple-topped EDTA vacutainers from the delivery packaging, wipe the outer surface of the vacutainer with either 10% terminex, 10% ChemGene, or appropriate decontamination reagent as per local procedures.
2. In the event of contamination of packaging (i.e. sample has leaked into packaging), attempt to rescue as much uncompromised sample as possible, decontaminate the delivery packaging as per local SOPs, and make a note of this in the log.

3. Retrieve StemCell kit from fridge, add 4x 50ml blue-lidded Falcon tubes to the hood. Invert EDTA vacutainers 2 times gently if separation has occurred.
4. Gently pour the collected blood from all of the vacutainers at a 45° angle into one combined 50 ml blue-lidded Falcon tube, carefully so as not to activate the neutrophils and avoid incorporating any bubbles. Leave vacutainers inverted for ~10 sec to ensure as much blood sample as possible has been added to the falcon tube. Record the approximate total volume of blood in the lab book and study log sheet, utilising the volume markers on the 50ml tube as a guide.
5. Add 50µl of Isolation Cocktail per mL of whole blood (colourless tube; e.g. add 1ml if 20ml blood was noted in the 50ml falcon tube for this preparation, add 900 µl if there is 18 ml blood, etc.). Record volume of cocktail added in the log sheet. Adjust according to total blood volume available.

Isolation kit typically has more bead volume than cocktail volume, so use this carefully and take any liquid that may have collected in the reagent tube cap if possible.

6. Vortex the RapidSpheres from the EasySep kit for 30 seconds (brown tube in kit) to resuspend them and add 50 µl/ml blood (use the same volume as in step 5) to the blood preparation.
7. Very gently invert end over end 4 times to mix, avoiding generation of bubbles (remove with p1000 if large bubbles form). Incubate for 5 minutes upright at room temperature in the hood (use lab timer). *Do not add to magnet yet.*
8. After 5 min, very gently pour or pipette pre-prepared 1X DPBS/1mM EDTA to top the blood sample up to a final volume of 50 ml. Securely re-cap the falcon tube. Carefully and slowly invert the tube 3 times to mix evenly.
9. Unscrew the falcon tube lid and place the tube of cells into the EasySep Magnet (silver Easy50 magnet). Incubate at room temperature for 10 minutes in the magnet.

A yellow-ish neutrophil-rich layer and darker red layer should form. Occasionally separation is not as clear on the first magnet step and the top layer remains pink, but should clarify with subsequent separation steps.

10. With a new 25ml stripette, slowly pipette up the top layer of cells keeping the stripettes tip at the very top of the liquid layer and moving down with it, avoiding any bubbles, and taking a maximum of 25ml each time. Transfer the top neutrophil-rich layer into a new 50ml blue lidded Falcon tube, taking care not to disturb the red cell layer. Dispose of the Stripette and the old blood tube as appropriate into the solid or liquid waste.
11. Add the Rapid Spheres at the same volume as in step 6 (vortex beads for 30 seconds before use to resuspend) to the newly transferred cells. Gently invert the suspension 3 times to mix and then incubate (not in magnet) for a further 5 minutes at room temperature. Return the Stem cell reagent kit to the fridge.
12. After 5 min, place the tube of cell suspension onto the EasySep Magnet. Remove the lid (or place on lightly) and incubate the cells on the magnet at room temperature for 5 minutes.
13. Repeat step 10 and transfer the neutrophil-rich plasma solution to a new 50ml falcon tube (do not add any further beads/RapidSpheres). Immediately add the transferred cell suspension to the magnet.

14. Incubate the tube on the magnet for 10 minutes at room temperature. Then start to opsonise the bacteria according to SOP K.
15. Collect purified Neutrophils into a new tube using a 25 ml stripettes. Remove 10 μ l of cell suspension and load this directly into a haemocytometer slide for cell counting. *No trypan blue addition is needed.*
16. Note the total volume of cell suspension in the 50 ml tube for later cell number calculations, then centrifuge the cells at 300 xg for 6 minutes with Acceleration 7, Brake 7 (setting depends on centrifuge at the site; medium acceleration and medium brake are required). Ensure the centrifuge is at room temperature.
17. Whilst the cells are undergoing centrifugation, conduct cell counts. Use the total cell volume from step 16 to calculate the final cell number. Then, calculate the volume of DPBS needed to resuspend the cells at a concentration of 5×10^6 cells/ml (calculations below; note all cell numbers and calculations in log sheets).
18. After the centrifugation cycle completes, using a 25mL Stripette, gently remove the plasma supernatant and discard into liquid waste. Leave behind a small volume of buffer (max ~ 1 ml) if needed to avoid accidentally removing and discarding cells from the pellet.
19. Gently resuspend the white cell pellet in 10 ml of DPBS to wash using a 10 ml stripette, pipetting up and down 3 times.
20. Pellet cells once again by centrifuging at 300 xg for 6 min.
21. Remove and discard the supernatant by gently pouring this into liquid waste, leaving the tube inverted for ~ 2 seconds, and then resuspend the cell pellet in the calculated volume of DPBS (without EDTA) to achieve the desired cell concentration (5×10^6 /ml); for this, use a p1000 pipette to gently and evenly resuspend the pellet in 1 ml of DPBS initially, then use a stripette to top up the suspension to the correct final volume. Cap the tube securely and invert gently end-over-end 3 times to mix cells evenly. Cells can now be used for further live assays and storage according to the priority list below.

Order of priority for isolated neutrophil usage:

1. *1x pellet storage (5×10^6 cells)*
 2. *1x RNALater storage (5×10^6 cells)*
 3. *Functional work*
 - i. *SYTOX NETs assay (2×10^6 cells; assay uses 8×10^5 cells, but some excess is required for accurate plate loading)*
 - ii. *Phagocytosis assay (2×10^6 cells)*
 - iii. *ROS assay (2×10^6 cells)*
 - iv. *Cell stimulation and storage (9×10^6)*
 4. *2x further pellet storage (5×10^6 cells)*
22. **For cell pellet storage**, aliquot 1ml of neutrophil suspension into a pre-labelled (participant ID, visit, date) 1.5 ml Eppendorf LoBind protein tube, in triplicate, and centrifuge 300 xg for 5 mins to pellet.

To allow pellet generation before moving on to functional work, use the below as a guide to determine the number of 1.5ml LoBind tubes to fill and centrifuge:

Neutrophil count	Number of 1.5 ml LoBind neutrophil tubes to generate before proceeding to functional work
29.9 million or less	2 (1 pellet, 1 RNAlater lysate)
30 to 34.9 million	3 (2 pellets, 1 RNAlater lysate)
35 million or more	4 (3 pellets, 1 RNAlater lysate)

23. Remove and discard supernatant from the Eppendorf tubes. Except for the tube reserved for RNAlater, immediately snap freeze up to 3 tubes/cell pellets (if cell number permitted) by putting these into a pre-cooled Corning CoolRack block in the -80°C freezer. Transfer to permanent storage after minimum 2h in the block (maximum time is indefinite, but recommend doing this within 24-48h to avoid losing sample tubes due to other freezer usage, as block is not lidded).


For permanent storage and shipping, pellets are very sensitive to rapid thawing, ensure samples are always handled on dry ice and storage boxes are never out on the bench at room temp for any time period.

24. To the other RNAlater Eppendorf tube (sample #2 in priority list), gently resuspend the cells in $100\ \mu\text{l}$ DPBS by pipetting 3 times. Add $500\ \mu\text{l}$ RNAlater buffer, then pipette up and down with a p1000 pipette vigorously 10 times to homogenize and lyse cells. Store immediately at -80°C in appropriate box.

25. Proceed to live neutrophil functional assays with remaining cells.

Calculation for cell counting

- 1. No. of cells in a 4x4 grid on the haemocytometer multiplied by $10^4 = \text{cells/ml}$
- 2. **Cells/ml** multiplied by the **volume of the original cell suspension** = **total cell number**
- 3. **Total cell number** divided by 5 million = **volume of DPBS (without EDTA) needed** to resuspend total neutrophil pellet to achieve 5×10^6 cells/ml



Count any one of the grids outlined in red in A. Counting more than one 4x4 grid is not necessary. However, if this is done, ensure the average count per 4x4 grid is used for the first calculation above. Do not include the cells crossing two outer-most edges of the grid, as per B above (indicated by X).

8.10. SOP J *In vitro* neutrophil extracellular trap (NETs) assay with SYTOX green (visits 2 and 5)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves/Long cuff gloves	P1000, P200 and p10 multichannel pipettes, p10 single channel pipette tips
Lab coat	Incubator (37°C) with 5% CO ₂ with humidity (<i>get in touch with Tayside site if humidity is not maintained for alternative solutions</i>)
Fluorescence plate reader for 96-well plates	Clinical waste bags & autoclave tape (or as per local procedures)
Microbiological Safety Cabinet MSCII	2x Disposable reagent trough/well (provided to sites)
PA10 LPS (Sigma L9143-10MG) (provided as 0.5 mg/ml stock in dH₂O) (stored at -20°C)	1x 96-well TC-treated NUNC plate with lid (provided to sites)
PMA (Sigma P1585-1MG) (provided as 10 µM stock) (stored at -20°C)	RPMI with 10mM HEPES (no phenol red, NO SERUM) (stored at 4°C)
Salmon sperm DNA standard (provided as 5 µL 1mg/ml stock aliquots, stored -80°C)	Sytox green DNA dye (provided to sites as 5µM stock ready to use and made up in 10 ml dH₂O) (stored at -20°C)
Nuclease-free water (provided as 13ml in 15ml falcon tubes) (stored at -20°C)	Sterile PBS (stored at room temp)
Vortex	8x sterile nuclease-free 15 ml tubes
	Plate control sample in 1.5ml tube (FBS; Store -80°C)

Notes:

Fluorescence plate reader must be regularly serviced and maintained with in-date certificate.

RPMI media preparation: Add 0.25 ml HEPES to 24.75ml Phenol-red-free RPMI. Keep any excess in the fridge, label tube with the study, reagent name, date, and your initials, and use within 1 month. Warm to room temp for use ~30 min before required.

Procedure:

1. On the day of the assay, remove the sterile 13 ml DNase-free water aliquot from the -20°C freezer, thaw at room temperature ready for later use.
2. Label the 96-well plate lid with the plate conditions and plate plan shown below using a permanent marker (all conditions have quadruplicate wells). Vortex all stock reagents and working solutions before pipetting.

3. In 1.5ml Eppendorf tubes generate working solutions:
 - a. Add 10.5 µl LPS to 990 µl RPMI/HEPES media
 - b. Add 10.5 µl PMA to 990 µl RPMI/HEPES media
 - c. and d. Add 10.5 µl PBS to 990 µl RPMI/HEPES media (vehicle control) make this in duplicate (i.e. make two tubes of the vehicle control working solution)

Plate layout:

	Column #: 1, 2, 3, 4	5, 6, 7, 8	9, 10, 11, 12
Row A	1. Unstimulated cells	2. LPS	3. PMA
Row B	4. <i>Cells WITHOUT SYTOX</i>	5. Media only (no cells or SYTOX)	6. Media and SYTOX only (no cells)

1. Unstimulated control cells (190 µl PBS vehicle working solution per well) (row A, wells 1-4)
2. LPS – 5 µg/ml (190 µl LPS working solution per well) (row A, wells 5-8)
3. PMA – 100 nM (190 µl PMA working solution per well) (row A, wells 5-8)
4. Cells only (no SYTOX) (190 µl PBS vehicle working solution per well) (row B, wells 1-4)
5. Media only (no cells or sytox green) (200 µl RPMI/HEPES media per well) (row B, wells 5-8)
6. Sytox Green only (no cells) (200 µl RPMI/HEPES media per well) (row B, wells 9-12)

n.b. media used in this assay should be sterile RPMI media containing 10mM HEPES (no phenol red, no serum) to each well as below (final well volume should be 200µl):

4. All steps above can be prepared in the morning on day of use, then refrigerate the prepared plate after reagent addition. **~30 min before use** (as an estimate a good time to do this is on the first centrifugation step after the last StemCell magnet step in the cell isolation), remove the prepared plate from fridge and store at room temp inside the hood to allow to come to room temp. If two participants are expected at the same time, only one “Sytox only/no cells” control and only one sperm DNA standard curve and DNA plate control is required per plate.
5. Isolate neutrophils using EasySep Kit. SOP I Neutrophil isolation with EasySep kit and neutrophil storage.

CONTINUE HERE AFTER NEUTROPHIL ISOLATION:

6. Using a white plastic disposable reservoir, add isolated neutrophils at 5×10^4 cells per well (i.e. 10 µl per well of the 5×10^6 cells/ml suspension in DPBS) to plates using a 10 µl multichannel pipette, for all conditions except
 - v. “Media only” (no cells or sytox green) (row B, wells 5-8)
 - vi. “Sytox green only” (no cells) (row B, wells 9-12)

Pipette up and down once when adding the 10 µl cell suspension, without introducing bubbles. Ensure all solution is removed from every tip by visual inspection. Use fresh tips for each well/addition.

7. Incubate plate for 3 hours and 50 min at 37°C, 5% CO₂, with humidity, then proceed to step 9.

8. **At 3h and 35 mins**, thaw an aliquot of the DNA stock solution to room temperature for 5 mins. Also remove the SYTOX green stain from the freezer to thaw to room temperature at this time, and remove the plate control FBS aliquot to thaw. Then proceed to generate a DNA standard curve as follows:
 - i. Set out 8x 15ml DNase-free sterile falcon tubes, **carefully ensuring no DNA contamination during set up. Clean the hood before preparation if needed.** Number these tubes 1 to 8.
 - ii. To the 5 µl DNA stock aliquot in 1.5ml tube from the -20°C freezer, add 620 µl of Nuclease-free water (provided as 13 ml aliquots, stored at -20°C until day of use) using a p1000 pipette. Vortex for 5 seconds to mix.
 - iii. To tube 1, add 2.7 ml nuclease-free water. To tubes 2-7, add 1 ml of water. To tube 8, add 2 ml water.
 - iv. To tube 1, add 300 µl of DNA solution prepared in step ii.
 - v. Vortex the tube for 5 seconds to mix.
 - vi. Take 2 ml of the newly generated solution from tube 1 and add to tube 2, pipetting up and down ~4 times.
 - vii. Vortex tube 2 for 5 seconds, take 2 ml from tube 2 and add this to tube 3.
 - viii. Repeat this serial dilution process iteratively to generate subsequent dilutions until **tube 7**. At the end of the process, tubes 1-6 should have 1 ml DNA standard and tube 7 should have 3 ml.
 - ix. DO NOT ADD ANY DNA TO TUBE 8. Tube 8 will be the blank.

9. **At 3h and 50 mins**, remove the 96-well plate from the incubator, add the DNA standard curve to the plate according to the layout below, in quadruplicate, loading 200 µl of each standard, plate control (neat), or blank (i.e. water only) per well. Change tips when loading different concentrations.

	Column #: 1, 2, 3, 4	5, 6, 7, 8	9, 10, 11, 12
Row A	Unstimulated cells	LPS	PMA
Row B	<i>Cells WITHOUT SYTOX</i>	Media only (no cells or SYTOX)	Media and SYTOX only (no cells)
Row C	DNA 800 ng/ml (tube 1)	DNA 533 ng/ml (tube 2)	DNA 355 ng/ml (tube 3)
Row D	DNA 236 ng/ml (tube 4)	DNA 158 ng/ml (tube 5)	DNA 105 ng/ml (tube 6)
Row E	DNA 70 ng/ml (tube 7)	DNA blank (0) (tube 8)	<i>DNA blank (0) (tube 8), NO SYTOX</i>
Row F	Plate control sample	X	X

If two participants are being processed in parallel at the same time for either visits 2 or 5, repeat the conditions shown in rows A and B in rows G and H for the second donor's cells.

10. **At 4h exactly**, add 25 µl fully-thawed Sytox green to all wells shown in bold text above using a disposable plastic reservoir and P100 multichannel pipette. Pipette up and done just once gently. Use fresh tips for each well.
11. Read plate at excitation/emission 490/537 nm on the plate reader, removing the plate lid before reading. Keep plate inside the reader, and read again exactly 10 mins later (use a saved programme created in advance for the assay/study if possible).
12. Record the plate reader use and save file with time point, date, and sample ID (NET-site-participantID-visit). Include plate plan in the file if deviating from SOP plate layout. Store/send file into appropriate "AIR-NET NETs assay" folder, ensure cloud-based back up of the file is made either by copying to a secure online platform (e.g. SharePoint or Google Drive) if not done automatically on the plate reader computer.

Before disposing of the assay plate and before closing the original data read-out, immediately open the stored results file and check wells A1-4 fluorescence readings match those on the original read-out to any prevent saving errors. Initial the corresponding box in the log sheet to confirm this has been done.

13. Discard the plate into the biohazard waste bag after use or appropriate local waste stream.

8.11. SOP K *In vitro* neutrophil phagocytosis and reactive oxygen species assay (visits 2 and 5)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves/Long cuff gloves	<p>2x FITC-labelled heat-killed <i>P. aeruginosa</i> (PAO1) aliquots (see Tayside-only SOP N - FITC labelling of <i>P. aeruginosa</i>) with 10% normal human serum (<i>tube label "PA"</i>)</p> <p>1x 10 μl aliquot of normal human serum (Labelled "<i>S</i>"; to be added freshly to the "<i>PA</i>" tube)</p> <p>2x BSA/HBSS vehicle-control containing 10% serum (<i>Tube label "H/S"</i>)</p> <p>2x HBSS tubes for subsequent LPS/TNF addition (<i>Tube label "L/T"</i>)</p> <p>4x HBSS vehicle-control only (<i>Tube label "H/O"</i>)</p> <p>All stored at -20°C and provided as combined bacteria or vehicle and serum pre-prepared 30 μl aliquots in 1.5ml LoBind Eppendorf tubes</p>
Dedicated Lab coat/Face Guard	15x 5 ml round-bottomed flow tubes with lids (10 for assay, 5 required for flow cytometry analysis)
Centrifuge for 1.5ml Eppendorfs (room temp)	4% PFA/PBS (stored at 4°C)
Microbiological Safety Cabinet MSCII	Incubator (37°, 5% CO ₂)
Clinical waste bags & autoclave tape (or as per local procedures)	Sterile DPBS (stored long-term at room temp)
CellROX deep red reagent (stored at -20°C, Invitrogen™ C10422)	2% BSA/DPBS (stored at -20°C at receipt, once thawed for use, store 4°C up to 1 month)
Sterile HBSS (stored at room temp)	PA10 LPS (Sigma L9143-10MG) (provided as 0.5 mg/ml 100X stock in PBS) (stored at -20°C)
Foil (or equivalent method to protect samples from light)	TNF-Alpha 1000X stock (R&D; 210-TA-020/CF; stock in PBS)

Notes:

Heat-killing of bacteria has been previously validated and is checked for every batch of PAO1 prepared for AIR-NET. See appendix 1 for confirmation of current batch successful heat-inactivation and killing. No bacterial growth is observed after the process has been completed.

Procedure:

1. At the beginning of the day when preparing the other in-pate assays. Remove the following tubes from the freezer and thaw for 5-10 mins:
 1. 2x HBSS tubes for subsequent LPS+TNF addition (“L/T” to warm to room temp)
 2. 4x HBSS control tubes (“H/O” to warm to room temp)
2. Generate 1x further 1.5ml Eppendorf tube with 198 µl HBSS, label with “CellROX” and keep RT with the other tubes for later use to dilute stock CellROX stain.
3. Dilute the 1000X TNF stock from the freezer 1:10 to generate a 100X stock. For this, to the 20 µl TNF aliquot provided, directly add 180 µl sterile PBS. Vortex the tube to mix, and keep on ice until use. After use in step 4 below, quickly return the 100X TNF to the ice, and keep use in for SOP L, 12-well plate assay.
4. After 5-10 mins, add to both the 2x “L/T” tubes 2.3 µl of 100X LPS stock and 2.3 µl of TNF-alpha stock per tube.
5. **Also add an aliquot of frozen 2% BSA/DPBS to the fridge to slowly thaw for later use. Do not vortex BSA. If using a stock thawed for a previous visit, ensure it is within 1 month of initial thawing.**
6. Add all 7 tubes to the fridge. Remove from the fridge to warm to room temp on the bench again when the FITC-PAO1 (“PA”) are being opsonised in the incubator (Do not add the tubes above to the incubator until after the addition of neutrophils in step 7 below)
7. During the neutrophil isolation process, when the cell suspension is put onto the magnet for the last time (final 10 min incubation step), start to opsonise the pre-prepared, FITC-labelled heat-killed *P. aeruginosa*. For this, remove:
 1. 2x FITC-PA tubes (“PA” to incubate at 37°C)
 2. 2x serum+HBSS control tubes (“H/S” to incubate at 37°C)
 3. 1x 10 µl normal human serum aliquot

from the -20°C freezer. **Keep samples protected from light for the whole procedure to avoid bleaching the fluorescence.**

Thaw the 1x serum aliquot quickly in a gloved hand, then immediately add 3 µl of this serum to each of the 2x “PA” tubes. Do not add to the H/S tube as this already contains serum. Discard any remaining serum from the small aliquot and do not re-freeze.

Add tubes in 1 and 2 (i.e. 2x FITC-PA “PA” tubes, 2x serum+HBSS control “H/S” tubes) into a rack in a 37°C incubator for 30 minutes, **protected from light.**


Then, put the 7x refrigerated tubes prepared earlier (2x “L/T and 4x H/O”, plus 1x HBSS for CellROX dilution) onto the bench to warm to room temp.

1. Remove the CellROX stock from the freezer to thaw for ~10 mins before use. Briefly centrifuge the tube (~5 seconds) to allow liquid accumulated in the lid to be utilised.
2. Once opsonisation is completed at 37°C for 30 min, and once the other tubes have been at room temp for 30 min, **(in a hood with the light turned off if possible)** label all of the 1.5ml Eppendorf

tubes with the participant ID. If pure neutrophils are not yet ready, keep the tubes protected from light at room temp.

3. Generate a CellROX concentrated solution by adding 2 μl of full-thawed CellROX stock to the extra pre-prepared tube containing 198 μl HBSS. Vortex for 5 seconds to mix.
4. Add 20 μl of the diluted CellROX stain (generated in step 3) to 4 tubes: two of the "H/O" HBSS only (ensure 2 further "H/O" HBSS only tubes remain unstained) and two "L/T" LPS/TNF tubes. 4 tubes in total should now contain CellROX stain. **Add a star (*) to the lids of these tubes with permanent marker to distinguish them from the rest.**
5. Add 100 μl room-temperature HBSS (from the larger stock HBSS bottle) to each of the 10 experiment Eppendorf tubes, then add 100 μl of the final isolated neutrophil suspension to each of the 10 tubes (cells should have been prepared in DPBS at a concentration of 5×10^6 neutrophils per ml just after isolation was complete, therefore 0.5×10^6 neutrophils in total are being added to each Eppendorf tube in this assay).

Tubes should now be as follows:



6. Invert all of the Eppendorf tubes gently 2 times to mix. Never vortex the cells. Incubate the samples at 37°C, 5% CO₂ for 30 min.
7. After 30 min incubation, add 300 μl of cold (4°C/refrigerated) 2% BSA/DPBS to each tube. Invert twice gently to mix.
8. Use a microcentrifuge to wash and the pellet cells (400xg for 5 mins, room temperature).
9. The cell pellet should be visible as a small white dot towards the bottom of the tube. Visually locate the pellet (do this for all wash steps), then carefully remove and discard the supernatant into liquid waste with a p1000 pipette, avoiding the edge with the pellet to prevent disturbing the cells with the tip or taking off the supernatant too quickly.
10. Resuspend the cell pellet in 500 μl cold DPBS (4°C/refrigerated) using a p1000 pipette. *If the pellet is accidentally removed at any step, pipette out the solution containing the cells back into the tube, add the DPBS to wash as above, and proceed to step 11. Make a note of this in the log sheet.*
11. Pellet cells once more (400xg for 5 mins, room temp).
12. Resuspend cells in 150 μl of 4% paraformaldehyde (PFA). Incubate protected from light at 4°C for 1 hour to fix and stabilise the cells.
13. After 1 hour, pellet the cells at 400xg for 5 mins.

14. Remove the PFA supernatant as described in step 9 and discard into special/hazardous waste as appropriate per local procedures.
15. Resuspend cells in 0.5 ml cold 2% BSA/DPBS to wash, pellet by centrifugation at 400xg for 5 mins.
16. Remove and discard the supernatant. Resuspend cells in 400 µl 2% BSA/PBS and transfer to 5ml round-bottomed polystyrene flow cytometry tubes (with lids).
17. Ensure 5 ml tubes are clearly labelled with permanent marker, adding a large star (*) again to those with ROS stain “*H/O” and “*L/T”. Cover samples with foil to protect from light, and store at 4°C until analysis (maximum 28h after preparation).

For flow cytometry analysis, see SOP M

Version 5

8.12. SOP L *In vitro* neutrophil stimulation in 12-well plates (visits 2 and 5)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	Microbiological Safety Cabinet MSCII
Dedicated Lab coat	Blood-isolated neutrophils (9×10^6)
Clinical waste bags & autoclave tape (or as per local procedures)	Sample labels (supernatants and lysates)
Sterile water	RIPA buffer (1X stock in dH₂O; Abcam #ab156034) Store refrigerated for up to 6 months.
Eppendorf/lysate storage box	6x 1.5 ml LoBind Eppendorfs
8x 0.9ml FluidX tubes and white tube caps	TNF-Alpha 1000X stock (R&D; 210-TA-020/CF; stock in PBS) <i>Made into a 100X stock in SOP K, and kept on ice until use</i>
RPMI media (Fisher sci; 10363083) with 10mM HEPES and 10% HI low-endotoxin FBS (Thermo; A4766801)	PA10 LPS (Sigma L9143-10MG) (provided as 0.5 mg/ml 100X stock in PBS) (stored at -20°C)
Protease Inhibitor Cocktail (Merck; P8340-1ML; 100X stock in DMSO)	PhosSTOP phosphatase inhibitor (100X stock, Merck 4906845001)
Sterile PBS (store room temp)	PMSF 100mM/100X stock (Thermo; 36978)
12-well sterile tissue culture plate (Thermo, Nunc, 150628)	Ice (and ice box)
FluidX supernatant storage box	Incubator (37°C) with 5% CO ₂ with humidity (<i>get in touch with Tayside site if humidity is not maintained for alternative solutions</i>)

Preparation notes:

RPMI media preparation: Add 5ml thawed (from -20°C freezer) heat-inactivated FBS to 0.5ml HEPES and 44.5ml Phenol-red-free RPMI. Keep any excess in the fridge and use within 1 month. Warm to room temp for use ~30 min before required.

On the day of use for RIPA: Aliquot 1.455 ml of 1XRIPA from the fridge into a 1.5ml Eppendorf tube, add 15 µl of PMSF (1:100; 20ul aliquots stored at -80°C), 15 µl protease inhibitor cocktail (1:100; 20ul aliquots of original stock stored at -20°C), and 15 µl PhosSTOP (1:100; 20ul aliquots of original stock stored at -20°C). Store complete solution on ice. Do not re-use solution for subsequent days once inhibitors have been added. **PMSF stock is generated in alcohol, use immediately from freezer, do not keep PMSF stock on ice before use as it will evaporate.**

Procedure:

1. One the morning of use, add 690 μ l RPMI/10mMHEPES/10%FBS media to **8** wells of a 12-well plate. Store in the fridge until 30 mins before use, then bring into the hood to warm for 30 mins to room temp.
2. Add 300 μ l of isolated neutrophils in DPBS (1.5 million cells since cells are at 5×10^6 /ml after isolation) to **6** of these wells (shown in **bold** on the plate layout).
3. Add 300 μ l DPBS (no neutrophils) as a vehicle control to wells A3 and A4
4. Incubate the plate for 60 min at 37°C, 5% CO₂ with humidity (use humidity chamber if incubator does not have water by default) to allow cells to settle and adhere to wells.
5. After 1h, in duplicate, to each of 2 wells with neutrophils per condition add:
 - 10 μ l of sterile PBS (vehicle; A1-2)
 - 10 μ l of 100X TNF (B1-2; use the 100X stock generated from SOP K, which should have been kept on ice)
 - 10 μ l of 100X LPS (C1-2)
6. To the wells without cells (media only) in A3-4, add 10 μ l PBS (vehicle) as per the scheme below.

Plate layout:

	Column 1	Column 2	Column 3	Column 4
Row A	Cells + media + PBS	Cells + media + PBS	Media + PBS (no cells)	Media + PBS (no cells)
Row B	Cells + media + TNF	Cells + media + TNF		
Row C	Cells + media + LPS	Cells + media + LPS		

Bold text indicates wells to which neutrophils should be added. Non-bold text indicates no cells.

7. Incubate the plate for a further 30 min, 37°C, 5% CO₂ with humidity to allow cell stimulation to occur.
8. Remove plate from incubator, collect 800 μ l of supernatant per well into pre-labelled (sample ID, date) 0.9ml FluidX tubes tube for each well. Pipette at the side of the well to avoid removing cells. **Do not tip/angle plate, keep flat on the hood surface to avoid cell detachment and loss. If less than 800 μ l can be collected, proceed with the available volume and record estimated volume in log sheet notes.**
9. Wash cells in the plate very gently by adding and then gently removing 1 ml of cold (ice-chilled) DPBS to each well. Pipette at the sides of the wells to prevent scratching adherent cells.
10. When DPBS has been added to all 6 cell-containing wells **in bold text** in the plate plan above (do not process the cell-free control well any further as no lysate can be obtained), then start to gently remove and discard the remaining supernatant from each well sequentially, discarding all the liquid from the well. **Do not tip/angle the plate, keep flat on the hood surface to avoid cell loss.**
11. After the first well supernatant has been removed, add 200 μ l complete, ice-cold complete RIPA buffer to that well, before proceeding to remove all DPBS supernatant from the next well and adding RIPA buffer. Repeat the process until all wells have been washed and have RIPA added. Ensure cells are not left dry for more than ~10 sec.

12. Bend the end of a p1000 tip by pushing it down into an empty well of the plate, and use the flattened end to scrape the wells to detach the cells (scrape 5x diagonally in one direction, then repeat in the opposite direction 5x, then scrape 5x in a circle around the well including the edges).
13. Use the tip with a p1000 pipette to collect the cell lysate into 1x pre-labelled Eppendorf tube per well. Plate can be angled to 45° at this step to ensure collection of all lysate.
14. Repeat with a new bent p1000 tip for each well until all lysates are collected.
15. Incubate the cell lysate in Eppendorf tubes on **ice** for 30 min to allow lysis to occur.
16. Meanwhile, store and log the supernatant samples in FluidX boxes.
17. After 30 min, store the Eppendorf tubes in the -80°C freezer and complete the log.

Version 5

8.13. SOP M Flow cytometry analysis of ROS and phagocytosis assay samples (visits 2 and 5)

Equipment/ reagents required (items in bold are provided by central site):

Nitrile gloves	8 x prepared samples in 5ml flow cytometry tubes
Dedicated lab coat	Trypan blue
P1000 pipette and tips	5x 5ml flow cytometry tubes for beads and buffer-only control
Biolegend Rainbow Calibration Particles, 8 peaks (3.0-3.4 µm; # 422903). 5ml (stored at 4°C)	2% BSA/DPBS
Invitrogen™ AccuCheck™ ERF Reference Particles, 3 peaks (#17166388) (stored at 4°C)	Calibrated flow cytometer (parameters: forward scatter, side scatter, detection of FITC and APC fluorescence)
Vortex	

Notes:

See appendix 2 for initial flow cytometry plot set up guidance. Set up should be completed before the first participant baseline sample is due to be run.

Flow cytometer must be regularly serviced and maintained, in addition to appropriate in-date calibration performed.

Rainbow calibration beads provided for AIR-NET are utilised in each experiment to generate an 8-peak standard-curve based on fluorescence values to normalise the final sample across all participating trial sites and machines. AccuCheck 3-peak beads are used as an assay control to determine variability.

Beads provided by Tayside site for this assay should not be used locally to calibrate the flow cytometer.

Run all samples on the “low” speed setting to avoid misidentification of single cells.

Follow local SOPs for flow cytometer use, including best practises such utilising a 30 min warm-up time for the machine to allow laser and delivery system set up before use.

Procedure:

- 1. Ensure flow cytometer has received daily calibration (e.g. CS&T beads run and passed). If not, run this before beginning any further analysis. Ensure the flow cytometer had been switched on ~30 mins or more before use to allow laser warming time.**
2. Prepare the 5x new 5ml tubes by initially adding 350 µl 2% BSA/DPBS per tube. Label these as 1, 2, 3, 4, and 5. Take AIR-NET trypan blue solution, along with the prepared samples and the beads to the flow cytometer.
3. Generate a new experiment in the flow cytometry software utilising the **template** generated in Appendix 2 (initial flow cytometry set up should be done before the first participant sample is run, and a template saved for re-use throughout AIR-NET).

4. Add in the experiment template, and name the new overall experiment as the sample ID (NET-site-participantID-visit) and the date of the sample run (dd.mm.yyyy).
5. Ensure there are empty sample “tubes” within the experiment for each of the following, and add the sample ID to the name:

Experiment name: “BEADS- NET-site-participantID-visit”

1. NET-site-participantID-visit 8-peak beads A
2. NET-site-participantID-visit 8-peak beads B
3. NET-site-participantID-visit 3-peak beads A
4. NET-site-participantID-visit 3-peak beads B

Experiment name: “CELLS- NET-site-participantID-visit”

5. NET-site-participantID-visit 2% BSA-DPBS only
 6. NET-site-participantID-visit unlabelled CellROX control A
 7. NET-site-participantID-visit unlabelled CellROX control B
 8. NET-site-participantID-visit CellROX unstimulated A
 9. NET-site-participantID-visit CellROX unstimulated B
 10. NET-site-participantID-visit CellROX LPS-TNF A
 11. NET-site-participantID-visit CellROX LPS-TNF B
 12. NET-site-participantID-visit unlabelled phago control A
 13. NET-site-participantID-visit unlabelled phago control B
 14. NET-site-participantID-visit FITC-PAO1 A
 15. NET-site-participantID-visit FITC-PAO1 B
6. Once the flow cytometer and experiment have been set up and samples are ready to be run, and the flow cytometer had confirmed to have an in-date “passed” calibration step run, vortex the **Biolegend 8-peak beads** for 10 seconds, then add one drop to tube 1 by squeezing the tube gently.
 7. Vortex the new solution for 3-5 seconds. Protect all samples including beads from direct light throughout to avoid photobleaching.
 8. Immediately acquire and then record the sample in the flow cytometer. Set the stopping gate to 25000 beads.
 9. Once the sample has almost completed running, vortex the **8-peak bead** stock tube again for 10 seconds, and repeat steps 6 to 8 to analyse this duplicate tube (tube 2).
 10. Repeat this process for the **AccuCheck 3-peak beads**, in duplicate, for tubes 3 and 4.
 11. Make up the bead solution freshly just before running each sample to ensure that bead aggregates are avoided.

Examples of the bead plots are shown in appendix 2. Ensure 8 or 3 bead populations can be observed as applicable in the APC vs. FITC dot-plot.

12. After the 4x bead tubes have been run, begin the CELLS analysis (i.e. neutrophil samples), in the order shown above starting from the BSA-only cell-free solution (tube 5), then the unlabelled control sample (tube 6), and continue in the order indicated in the list.

Run the cell-free buffer-only tube (tube 5) to determine background events. For this, keep the stopping gate set for the cells at 15000 events, but run the sample for 60 seconds, then manually stop the run. *As there are no cells or beads in the sample, the run will not stop automatically.*

13. If contaminating bead populations are noted in the buffer-only sample (tube 5), perform a machine “prime” step if needed, then re-run and record the buffer only.
14. **Do not vortex any of the cell samples**, but resuspend by gently flicking/tapping the tube approx. 5 times just before running.
15. For “CELLS” samples **12-15 only**, just before running each tube, add 100 µl trypan blue to the 5ml flow cytometry tube to quench membrane fluorescence. *Note: trypan must be added immediately before the running for each tube individually, do not add to all 4 tubes in parallel. As cells are fixed they may be more permeable and trypan blue may enter the cell over time, affecting the fluorescence of internalised fluorescent bacteria.*

Make a note in the lab book of any deviations, for example, if there are not enough cells to complete the run, if any sample is lost, any notes about the flow cytometer (for example slow/unexpectedly fast running of the sample, any errors).

16. Acquire and then record the sample in tubes 6-15 as above, setting 15000 single cells as the stopping gate for these tubes.

Examples of the cell plots for each assay are shown in appendix 2.

17. Export the fcs files for all tubes in the experiment and the batch analysis file (i.e. pdf file) for all tubes onto the computer or a secure storage device. Suggested folder naming is “AIR-NET” to hold all files, with sub-folders for each experimental run named as the full sample ID and date.
18. *Also upload all files into a secure cloud-based storage system to ensure the files are saved in two locations and backed-up.*

9. Appendices

9.1. Appendix 1: *Pseudomonas aeruginosa* PAO1 confirmation of heat-killing for use in SOP K and de-classification from category 2 containment requirement

Pseudomonas aeruginosa PAO1 strain was heat killed by incubation in a shaking incubator at 60°C for 1 hour as per Dicker et al., 2018, PMID: 28506850, before subsequent FITC-labelling for use in SOP K (phagocytosis assay).

To confirm successful bacterial killing with this step, duplicate LB agar spread plates were prepared by inoculating and spreading 100 µl heat-killed PAO1 (OD 600nm = 0.1) onto each plate, and then incubated for 5 days at 37°C.

To check that this method would successfully indicate the presence of any live bacteria, a further spread plate was generated with 100 µl live PAO1 (before the heat-killing step) at the same concentration as above and then grown under the same conditions.

Results:

After 5 days incubation, no bacterial growth was observed on either of the duplicate heat-killed PAO1 spread plates, and the LB agar remained clear (B and C below).

The live PAO1 control successfully grew as a lawn on the agar (A), confirming the validity of the assay and ability to detect live bacteria, when present.



Underside plate view:



9.2. Appendix 2: Flow cytometry set-up and gating guide (before first participant baseline visit)

Equipment/ reagents required (items in bold are provided by central site):


Nitrile gloves	3 x 5ml flow cytometry tubes
Dedicated lab coat	Vortex
P1000 and P200 pipettes and tips	2% BSA/DPBS
Biolegend Rainbow Calibration Particles, 8 peaks (3.0-3.4 µm; # 18631311). 5ml (stored at 4°C)	AccuCount Blank Particles (for initial set up only) (stored at 4°C) (10⁶/mL, 8.0-12.9µm, #ACBP-100-10-10ML)
Invitrogen™ AccuCheck™ ERF Reference Particles, 3 peaks (#17166388) (stored at 4°C)	Calibrated flow cytometer (parameters: forward scatter, side scatter, detection of FITC and APC fluorescence)

Follow local SOPs for flow cytometer use, including best practises such utilising a 30 min warm-up time for the machine to allow laser and delivery system set up before use, and observe all notes from SOP M, including valid daily calibration.

1. Add 1ml of 2%BSA/DPBS to each of 2x 5ml flow cytometry tubes, to a third tube, add just 350 µl.
2. Take the three bead sets in the equipment list above to the flow cytometer.
3. Generate a new folder in the flow cytometry software, call this “AIR-NET”, then generate an experiment within this folder and name this “AIR-NET set-up”.
4. Add three samples/tubes to the list:
 1. AccuCount Blank Particles
 2. 8-peak beads
 3. 3-peak beads




5. Before beginning to run any sample, ensure the following parameters are selected:
 1. FSC-A (forward scatter area) (don't use a log scale for FSC or SSC parameters)
 2. FSC-H (height)
 3. SSC-A (side scatter area)
 4. SSC-H
 5. Blue laser (488 nm) with 530/30 band pass filter, or as recommended on the specific flow cytometer to detect FITC fluorescence. Select both the area and height parameters.
 6. Red laser (633 nm) with 670/30 band pass filter, or as recommended on specific machine to detect APC fluorescence. Select both the area and height parameters.




6. Then set up the following plots in the flow cytometer software:


1. SSC-A (y-axis) vs. FSC-A (x-axis) dot-plot of all events. Then, generate a preliminary gate within this plot (this can be adjusted and corrected later) called “Neutrophils”. In the very bottom left corner of the plot, generate a further small circular gate, and call this “Beads”.




- 2.
3. FSC-H (y-axis) vs. FSC-A (x-axis) dot plot. On this plot, select the option to show only events from the “Neutrophil” gated population from plot 1. Generate a preliminary rectangular gate and call this “Single cells”.




4. FITC-A (or Blue 530/30 area, or equivalent setting for FITC fluorescence on specific machine) (y-axis) vs. APC-A (or Red 670/30 area, or equivalent) (x-axis). On this plot, select the option to show events from the “Beads” gate from plot 1. Do not generate any gates in this plot.





- SSC-A (y-axis) vs. APC-A (or equivalent as above) (x-axis) dot plot. On this plot, select the option to show "Single cells" only. Then, generate a preliminary gate approximately halfway between the second and third generation, as below. Call this gate "CellROX+"



- SSC-A (y-axis) vs. FITC-A (or equivalent for specific machine) (x-axis) dot plot. On this plot, select the option to show "Single cells" only. Then, generate a preliminary gate approximately halfway between the second and third generation, as below. Call this gate "FITC-PAO1+"




- Histogram plot of event count (y-axis) vs. APC-A (or equivalent) (x-axis). On this plot, select the option to show events from the "Beads" gate from plot 1. Do not generate any gates in this plot.
- Histogram plot of event count (y-axis) vs. FITC-A (or equivalent) (x-axis). On this plot, select the option to show events from the "Beads" gate from plot 1. Do not generate any gates in this plot.



- If not already autogenerated, add in the population hierarchy table to view event and gated population data, and also add mean and median fluorescence intensity to the table for observation whilst running samples.

Tube: AutoCount Blank Particles				FITC-A				APC-A			
Population	#Events	%Parent	%Total	Mean	Median	Mean	Median				
All Events	0	0.000	0.000	0.000	0.000	0.000	0.000				
Neutrophils	0	0.000	0.000	0.000	0.000	0.000	0.000				
Single cells	0	0.000	0.000	0.000	0.000	0.000	0.000				
CellROX+	0	0.000	0.000	0.000	0.000	0.000	0.000				
FITC-PAO1+	0	0.000	0.000	0.000	0.000	0.000	0.000				
Beads	0	0.000	0.000	0.000	0.000	0.000	0.000				


7. Voltages used on the BD Fortessa flow cytometer are provided below. If settings used for cell or neutrophil experiments in your lab previously are known, apply similar voltages as a starting point and adjust from there. If unknown, keep default settings for now.






8. Once the preliminary set-up is in place, the AccuCount Blank Particles can then be diluted and run:
9. Vortex the AccuCount Blank Particles for 20 seconds. Add 50 μ l vortexed particles to 1x 5ml tube containing 1 ml BSA/DPBS. Vortex this mixture for 3 seconds. *Note: these particles will be used as a surrogate for isolated human peripheral blood neutrophils, due to their similar size, to enable flow cytometry set up before participant samples are available for processing.*
10. In sample 1 on the experimental set-up (AccuCount Blank Particles) “Acquire” (but do not yet record) the AccuCount particles on the low setting initially. If required due to low event rate, speed can be increased to medium or high.




11. Adjust the forward and side scatter (FSC, SSC) voltages until the AccuCount particle population can be clearly observed in the top left corner of plot 1. “Refresh” the plot regularly if available as an option and if required to keep visualising the new location of the Particles on the plot during volage adjustments. Output values on the SSC/FSC scale may vary for different machines and optimal location on plot should be prioritised over achieving similar numeric output to that provided in the guide.




12. Once the voltage is adjusted and Particle location on the plot is satisfactory, now adjust the “Neutrophil” gate in plot 1 to loosely encompass this AccuCount Particle population, as above.
13. Check that there are now events displayed on plot 2 (FSC-H vs. FSC-A), and that only events occurring with the plot 1 “Neutrophil” gate are displayed within plot 2. Adjust the “Single Cells” gate in plot 2 to encompass the Particle population, as below. Then adjust the FITC and APC voltages (a.k.a Blue 530/30, Red 670/30, or equivalents) until the particle population can be visualised between the second and third generation in each of the relevant dot plots.




14. “Stop Acquiring” events. Remove the AccuCount Particles 5ml flow cytometry tube from the machine, **and keep this in a rack for later use**. Note the optimal FSC and SSC voltages down in case required later.
15. Next, vortex the Biolegend Rainbow Calibration Particles (8 peaks) for 10 seconds. Add 3 drops of these vortexed beads to a new 5ml flow cytometry tube containing 1ml BSA/DPBS. Vortex the mixture for 3 seconds.
16. “Acquire” (but do not yet record) the 8-peak beads on the low setting initially. If required due to low event rate, speed can be increased to medium or high.
17. Do not adjust the FSC or SSC voltages for this step. Adjust the “beads” gate in plot 1 to encircle the bead population.



- Adjust the FITC and APC voltages (a.k.a Blue 530/30, Red 670/30, or equivalents) until all 8-peaks of the bead population can be visualised on plot 3 (APC-A vs. FITC-A dot plot). Some bead aggregation may be seen as small populations nearby each major population. These can usually be distinguished and will be ignored in the analysis later on. However, if these are not distinguishable, re-vortex the sample to check if aggregates can be dispersed and run the sample again.




- Note the optimal voltage for these two parameters above, and then check that all bead populations have been correctly identified by turning down the voltage to approx $\frac{3}{4}$ and then $\frac{1}{2}$ of the optimal value. Check that there are no further bead populations with higher fluorescence which may have fallen off the top end of the scale. If no further populations appear, change the voltage back to the optimal noted value.



- “Stop Acquiring” events. Remove the 8-Peak Beads 5ml flow cytometry tube from the machine, and keep this in a rack for later use. Protect from direct light.
- Vortex the previously made and diluted AccuCount Particles (in the 5 ml tube) for 3 seconds. Add back onto the flow cytometer.
- Check all of the settings and voltages in the experiment sample 1 “AccuCount Blank Particles” are set to the optimised values determined above.
- Adjust the sample stopping gate to **15000 “Single Cells”**.
- “Acquire” on low speed. Once satisfied that the AccuCount Particles fall as expected within the “Neutrophils” and “Single Cells” gates, click “record”.
- Once completed, remove the AccuCount Particle 5 ml tube.
- Vortex the diluted 8-peak bead 5ml flow cytometry tube for 3 seconds.
- Add the 8-peak bead tube to the flow cytometer.
- Check all of the settings and voltages in the experiment sample 2 “8-peak beads” are set to the optimised values determined above.
- Adjust the sample stopping gate to **25000 “Beads”**.


30. Acquire" on low speed. Once satisfied that the 8-peak beads fall as expected within the "Beads" gate and that 8 populations are observed in the APC vs. FITC dot plot (plot 3), click "record".
31. Once completed, remove the 8-peak bead 5 ml tube.
32. Finally, vortex the Invitrogen™ AccuCheck™ ERF Reference Particles (3 peaks) for 10 seconds. Add 1 drop of these vortexed beads to a new 5ml flow cytometry tube containing 350 μl BSA/DPBS. Vortex the mixture for 3 seconds.
33. Add the 3-peak bead tube to the flow cytometer.
34. Check all of the settings and voltages in the experiment sample 3 "3-peak beads" are set to the optimised values determined above.
35. Adjust the sample stopping gate to **25000 Beads**.
36. Acquire" on low speed. Once satisfied that the 3-peak beads fall within the "Beads" gate and that 3 clear populations can now be observed in the APC vs. FITC dot plot (plot 3), click "record".



37. Once completed, remove the 3-peak bead 5 ml tube.

The flow cytometry set-up is now complete and the optimised plots and settings should be used for all AIR-NET participant samples run going forward. However, if needed, plot gates may be slightly adjusted for the individual participant sample to accommodate shifts in primary neutrophil size/shape.

38. Now set up the experiment for the first participant. In the "AIR-NET" folder, make 2 more sub-folders, "AIR-NET beads" and "AIR-NET cells"
39. Copy and paste the experiment "AIR-NET set-up" (without data) into both of these folders above.
40. In the re-name the experiment in each folder as per the scheme below. Add in the required number of samples (4 for beads, 11 for cells) and name these as below.



Ensure the stopping gate for all “beads” samples is set to 25000 beads.

Ensure the stopping gate for all “cells” samples is set to 15000 single cells.


Note: utilise the sample order from SOP M for running, not the order shown in the screenshot above.

41. WHEN RUNNING THE VERY FIRST PARTICIPANT SAMPLE ON THE FLOW CYTOMETER:







1. The FSC and SSC voltages may need to be slightly adjusted to ensure the neutrophils sit in the middle of the plot. The “neutrophil” gate can be adjusted to properly encompass the cells.
2. Once the set up has had minor tweaks after running the first AIR-NET sample set, **save each experiment as a “template”**.
3. The template should then be re-imported into the relevant AIR-NET cell and beads folders each time a new participant sample is run.
4. **After running the first ever sample, ensure that no adjustments are made manually to any of the voltages (aside from those automatically applied after daily flow cytometer calibration).**

An example of an AIR-NET sample run is shown below. (n.b. do not use "P1" shown in the first plot below in your experiment, P1 is a preliminary gate used for AIR-NET initial testing to investigate lymphocyte presence)



BD FACSDiva 9.7



BD FACSDiva 9.7




BD FACSDiva 9.7



Tube: NET-01-001-02 3-peak beads A







Population	#Events	%Parent	%Total
All Events	25,984	####	100.0
Neutrophils	2	0.0	0.0
Single cells	2	100.0	0.0
CellROX positive	1	50.0	0.0
FITC-PAO1 posi	0	0.0	0.0
Beads	25,000	96.2	96.2
P1	0	0.0	0.0





Population	#Events	%Parent	FITC-A Mean	FITC-A Median	APC-A Mean	APC-A Median
All Events	25,984	####	28,329	11,379	34,559	13,845
Single cells	2	100.0	180	180	3,859	3,859
CellROX positive	1	50.0	298	298	7,618	7,618
FITC-PAO1 positive	0	0.0	####	####	####	####
Beads	25,000	96.2	27,522	11,365	33,722	13,828
P1	0	0.0	####	####	####	####



BD FACSDiva 9.7




BD FACSDiva 9.7









Tube: NET-01-001-02 unlabelled cellROX control A

Population	#Events	%Parent	%Total
All Events	15,696	####	100.0
Neutrophils	15,229	97.0	97.0
Single cells	15,000	98.5	95.6
CellROX positive	6	0.0	0.0
FITC-PAO1 posi	17	0.1	0.1
Beads	16	0.1	0.1
P1	115	0.7	0.7





Population	#Events	%Parent	FITC-A Mean	FITC-A Median	APC-A Mean	APC-A Median
All Events	15,696	####	402	388	44	37
Single cells	15,000	98.5	395	389	39	37
CellROX positive	6	0.0	502	522	1,804	1,580
FITC-PAO1 positive	17	0.1	1,369	1,329	94	84
Beads	16	0.1	4,906	290	5,528	40
P1	115	0.7	192	179	10	8

BD FACSDiva 9.7




BD FACSDiva 9.7




Tube: NET-01-001-02 CellROX unstimulated A

Population	#Events	%Parent	%Total
All Events	15,853	####	100.0
Neutrophils	15,473	97.6	97.6
Single cells	15,000	96.9	94.6
CellROX positive	10,618	70.8	67.0
FITC-PAO1 posi	19	0.1	0.1
Beads	11	0.1	0.1
P1	102	0.6	0.6





Population	#Events	%Parent	FITC-A Mean	FITC-A Median	APC-A Mean	APC-A Median
All Events	15,853	####	422	395	917	698
Single cells	15,000	96.9	406	392	886	693
CellROX positive	10,618	70.8	438	427	1,062	833
FITC-PAO1 positive	19	0.1	1,748	1,274	4,847	497
Beads	11	0.1	437	311	1,196	481
P1	102	0.6	207	184	332	169

BD FACSDiva 9.7




BD FACSDiva 9.7





Tube: NET-01-001-02 CellIROX LPS-TNF A

Population	#Events	%Parent	%Total
All Events	16,906	####	100.0
Neutrophils	15,836	93.7	93.7
Single cells	15,000	94.7	88.7
CellIROX positive	15,000	100.0	88.7
FITC-PAO1 posi	41	0.3	0.2
Beads	68	0.4	0.4
P1	142	0.8	0.8




Population	#Events	%Parent	FITC-A Mean	FITC-A Median	APC-A Mean	APC-A Median
All Events	16,906	####	525	486	6,987	5,261
Single cells	15,000	94.7	495	482	7,026	5,329
CellIROX positive	15,000	100.0	495	482	7,026	5,329
FITC-PAO1 positive	41	0.3	1,387	1,234	11,074	5,882
Beads	68	0.4	327	270	1,081	873
P1	142	0.8	201	177	1,156	709

BD FACSDiva 9.7



Tube: NET-01-001-02 unlabelled phago control B







Population	#Events	%Parent	%Total
All Events	15,561	####	100.0
Neutrophils	15,131	97.2	97.2
Single cells	15,000	99.1	96.4
CellROX positive	14,980	99.9	96.3
FITC-PAO1 posi	17	0.1	0.1
Beads	45	0.3	0.3
P1	105	0.7	0.7









Population	#Events	%Parent	FITC-A Mean	FITC-A Median	APC-A Mean	APC-A Median
All Events	15,561	####	285	262	46,420	40,465
Single cells	15,000	99.1	273	262	42,606	40,164
CellROX positive	14,980	99.9	273	262	42,675	40,181
FITC-PAO1 positive	17	0.1	1,267	1,268	155,153	262,143
Beads	45	0.3	792	823	240,381	262,143
P1	105	0.7	155	142	33,314	29,817





BD FACSDiva 9.7



BD FACSDiva 9.7




BD FACSDiva 9.7









Tube: NET-01-001-02 FITC-PAO1 B

Population	#Events	%Parent	%Total
All Events	15,899	####	100.0
Neutrophils	15,311	96.3	96.3
Single cells	15,000	98.0	94.3
CellROX positive	14,986	99.9	94.3
FITC-PAO1 posi	2,450	16.3	15.4
Beads	68	0.4	0.4
P1	90	0.6	0.6





Population	#Events	%Parent	FITC-A Mean	FITC-A Median	APC-A Mean	APC-A Median
All Events	15,899	####	2,664	331	61,409	54,095
Single cells	15,000	98.0	2,414	326	55,572	53,459
CellROX positive	14,986	99.9	2,413	326	55,628	53,474
FITC-PAO1 positive	2,450	16.3	13,138	9,257	57,697	54,711
Beads	68	0.4	960	825	246,307	262,143
P1	90	0.6	188	152	30,529	28,637

BD FACSDiva 9.7




BD FACSDiva 9.7



Tube: NET-01-001-02 2% BSA-DPBS only

Population	#Events	%Parent	%Total
All Events	23	####	100.0
Neutrophils	5	21.7	21.7
Single cells	5	100.0	21.7
CellROX positive	3	60.0	13.0
FITC-PAO1 posi	1	20.0	4.3
Beads	0	0.0	0.0
P1	0	0.0	0.0



Population	#Events	%Parent	FITC-A Mean	FITC-A Median	APC-A Mean	APC-A Median
All Events	23	####	417	64	5,213	110
Single cells	5	100.0	1,306	465	11,776	2,186
CellROX positive	3	60.0	1,714	0	19,499	14,540
FITC-PAO1 positive	1	20.0	5,188	5,188	2,186	2,186
Beads	0	0.0	####	####	####	####
P1	0	0.0	####	####	####	####

BD FACSDiva 9.7

